

OAT MINCEMEAT SLICE



- 3oz porridge oats
- 3oz wholemeal flour
- 2oz. Brown sugar
- 3oz butter or margarine
- A good half teasp. Baking powder
- 8oz mincemeat

Put dry ingredients in a bowl and rub in butter or Margarine. Put half the mixture in a lined 8in sandwich tin. Spread the mincemeat onto mixture. Spread the rest of the mixture over mincemeat and press down firmly.

Cook for 30min at 180 C gas 5.

Mark segments while still hot.

Something different from mince pies. Enjoy!